



2/27





L


3/27




+







7/27



L

FIG. 8A




FIG. 8B





FIG. 9






FIG. 11A






FIG. 11B





13/27




FIG. 14A

COPYING CAN BE EXECUTED.								
100%	AUTOMATIC SHE	ET FEED 1						
NON- MAGNIFICATION	MAGNIFICATION •							
SHEET SELECTION		LIGHT AUTO DARK						
		CHARACTER -						
SORTER	DOUBLE-SIDED >	APPLIED MODE						

FIG. 14B





FIG. 14C



15/27

FIG. 15C

SELECTION OF MAINTENANCE ITEM FOR FOLDER	STOPPER POSITION ADJUSTMENT	FOLDING, ROLLIER, PRESSURE CONTACT FORCE ADJUSTIMENT		RETURN	
N FOR MAINTENANCE	FOLDER	BOOKBINDER	FINISHER	OK	
SELECTION OF SECTION FOR MAINTENANCE	PININTER	READER	AUTOMATIC SHEET FEEDER	RETURN	

FIG. 15D

(RANGE) (1-20)	
SETTING VALUE	
FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT	RETURN
	•

ISA	V FOR MAINTENANCE	FOLDER	BOOKBINDER	FINISHER	OK	15B	VANCE ITEM		EMENT	OK	
FIG.	SELECTION OF SECTION FOR MAINTENANCE	PIRINTER	READER	AUTOMATIC SHEET FEEDER	RETURN	FIG. 15B	SELECTION OF MAINTENANCE ITEM FOR FOLDER ADJUSTMENT	CLEANING	COMPONENT REPLACEMENT	RETURN	

EXECUTE AFTER COMPLETION OF JOB SWITCH TO MAIN SCREEN IT IS NECESSARY TO EXECUTE ADJUSTMENT ON OOO **EXECUTE IMMEDIATELY** FIG. 16C SWITCH TO MAIN SCREEN MAINTENANCE (ADJUSTMENT BEING EXECUTED) ... PLEASE WAIT FOR A WHILE ... FIG. 16A ABORT

SETTING (RANGE) VALUE SUB-MAINTENANCE ADJUSTMENT FIG. 16D 2 FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT

... PLEASE DEPRESS COMPLETION WHEN REPLACEMENT IS COMPLETED ...

MAINTENANCE (REPLACEMENT BEING EXECUTED)

FIG. 16B

-	Í	
ABOHI	SWITCH TO MAIN SCREEN	
COMPLETION	SWITCH	

RETURN

Š





FIG.~I8A

		18/2	27				
SUB-MAINTENANCE ITEM 2	2ND FOLDING POSITION ADJUSTMENT		2ND FOLDING POSITION ADJUSTMENT				
SUB-MAINTENANCE ITEM 1	FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT 1ST FOLDING POSITION ADJUSTMENT		1ST FOLDING POSITION ADJUSTMENT	2ND FOLDING POSITION ADJUSTMENT	FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT	
MAINTENANCE ITEM	FOLDING ROLLER REPLACEMENT	FOLDER CONVEYING ROLLER REPLACEMENT	1ST FOLDING STOPPER REPLACEMENT	2ND FOLDING STOPPER REPLACEMENT	FOLDER CONVEYING SENSOR 1 REPLACEMENT	FOLDER CONVEYING SENSOR 2 REPLACEMENT	
ITEM	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	
MODULE	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	

FIG.~18B

				1	19/2	7					
7											
				2ND FOLDING POSITION ADJUSTMENT						FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT
	FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT	FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT	1ST FOLDING POSITION ADJUSTMENT	2ND FOLDING POSITION ADJUSTMENT	FOLDING ROLLER CLEANING	FOLDING CONVEYING ROLLER CLEANING	1ST FOLDING STOPPER CLEANING	2ND FOLDING STOPPER CLEANING	FOLDER CONVEYING SENSOR 1 CLEANING	FOLDER CONVEYING SENSOR 2 CLEANING
	ADJUSTMENT	ADJUSTMENT	ADJUSTMENT	ADJUSTMENT	ADJUSTMENT	CLEANING	CLEANING	CLIEANING	CLIEANING	CLIEANING	CLEANING
	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER

FIG. 19



21/27






FIG. 20B




FIG. 21A




FIG. 21B




FIG. 22

